





MANDATORY BULLETIN

MB No: L 13/098a

Concerning: Maintenance Manual L-13AC BLANIK Sailplane (Do-L13AC-1032.3)

Reason: Max. airspeed placard adaptation.

Replace original pages 0-3, 0-7, 0-9 and 3-14 by new ones with date Jan

25/02.

To be carried out at the latest by:

Immediately after receiving this bulletin.

To be carried out by:

Owner.

Costs to be covered by:

No cost arise.

Necessary material to be supplied by: Revised pages are enclosed.

Bulletin becomes effective:

Since receiving this bulletin.

Manhours required:

Total number of pages:

1+4 enclosure pages.

Manufacturer

Engineering data contained in this Bulletin is CAA Approved.

Date: April 30, 2002



MAINTENANCE MANUAL

RECORD OF ISSUED BULLETINS

Serial. No. of Bull.	No. of Bulletin L 13 AC/	Issue date	Numbers of pages to which bulletin applies	Date of insertion in this issue and signature
1	L 13 AC/004d	Feb 18/00	0-3, 0-9, 3-29	
2	L 13 AC/005d	Aug 15/01	0-3, 0-7, 0-9, 0-12, 0-16, 13-1 to 13-10	
3	L 13 /096a	Sep 10/01	0-3, 0-7, 0-9, 2-5	
4	L 13 /098a	Jan 25/02	0-3, 0-7, 0-9, 3-14	



LET, a.s.

L - 13 AC BLANIK

MAINTENANCE MANUAL

Serial. No. of Bull.	No. of Bulletin L 13 AC/	Issue date	Numbers of pages to which bulletin applies	Date of insertion in this issue and signature
1			**	
			*	
				ż



L - 13 AC BLANK MAINTENANCE MANUAL

RECORD OF REVISIONS

Serial. No. of	Number of bulletin	Numbers of Pages			Date of	Date of insertion in this issue and
revision	L 13 AC	Rev. Pages	New. Pages	Del. Pages	Revision	signature
1	L 13 AC/004d	0-3	:=	=	Feb 18/00	
		0-7	ä	3		
		0-9	*	ā.		
		3-29	*	*		
2	L 13 AC/005d	0-3	3	•	Aug 15/01	
		0-7	5	5		
		0-9	*	-		
		0-12	2	±		
		0-16	<u> </u>	ã		
		5 = 3	13-1	=		
		E•c	to	-		
		(2 5	13-10	*		
3	L 13 /096a	0-3	ä	næi	Sep 10/01	
		0-7	*			
		0-9	*	> -		
		2-5	-	(4)		
4	L 13 /098a	0-3	5	AST	Jan 25/02	
		0-7		x.e.		
		0-9	¥	() €		
		3-14	ŭ	(2)		



L - 13 AC BLANIK MAINTENANCE MANUAL

Serial. No. of	Number of bulletin	N	Numbers of Pages		Date of	Date of insertion
revision	L 13 AC	Rev. Pages	New. Pages	Del. Pages	Revision	in this issue and signature
						K
	-					
5						
1						
	1					
			Į.			
)						



LIST OF EFFECTIVE PAGES

Chapter	Page	Date
Tittle page	Ħ	
0 General	0 - 1 0 - 2	June 30/98 June 30/98
Record of issued bulletins	0 - 3 0 - 4	Jan 25/02 June 30/98
Record of temporary revisions	0 - 5 0 - 6	June 30/98 June 30/98
Record of revisions	0 - 7 0 - 8	Jan 25/02 June 30/98
List of effective pages	0 - 9 0 - 10 0 - 11 0 - 12	Jan 25/02 June 30/98 June 30/98 Aug 15/01
Table of contents	0 - 13 0 - 14 0 - 15 0 - 16	June 30/98 June 30/98 June 30/98 Aug 15/01
1 Introduction	1 - 1 1 - 2 1 - 3 1 - 4 1 - 5 1 - 6	June 30/98 June 30/98 June 30/98 June 30/98 June 30/98
2 Inspections	2 - 1 2 - 2 2 - 3 2 - 4 2 - 5 2 - 6 2 - 7 2 - 8 2 - 9 2 - 10	June 30/98 June 30/98 June 30/98 June 30/98 Sep 10/01 June 30/98 June 30/98 June 30/98 June 30/98
3 Servicing	3 - 1 3 - 2 3 - 3 3 - 4 3 - 5 3 - 7 3 - 8 3 - 9 3 - 10	June 30/98 June 30/98 June 30/98 June 30/98 June 30/98 June 30/98 June 30/98 June 30/98

Chapter	Page	Date
3 Servicing	3 - 11 3 - 12 3 - 13 3 - 14 3 - 15 3 - 16 3 - 17 3 - 18 3 - 20 3 - 21 3 - 22 3 - 23 3 - 24 3 - 25 3 - 26 3 - 27 3 - 28 3 - 29 3 - 30 3 - 31 3 - 32	June 30/98
4 Fuselage	4 - 1 4 - 2 4 - 3 4 - 4 4 - 5 4 - 6 4 - 7 4 - 8 4 - 10 4 - 11 4 - 13 4 - 14 4 - 15 4 - 16 4 - 17 4 - 18 4 - 19 4 - 20 4 - 21 4 - 22 4 - 25 4 - 26 4 - 27 4 - 28 4 - 29	June 30/98



LET, a.s.


L - 13 AC BLANIK MAINTENANCE MANUAL

Chapter	Page	Date
4 Fuselage	4 - 30 4 - 31 4 - 32 4 - 33 4 - 34 4 - 35 4 - 36	June 30/98 June 30/98 June 30/98 June 30/98 June 30/98 June 30/98
5 Wing	5 - 1 5 - 2 5 - 3 5 - 4 5 - 5 5 - 7 5 - 8 5 - 10 5 - 13 5 - 14 5 - 15 5 - 16 5 - 17 5 - 18 5 - 19	June 30/98 June 30/98
6 Tail unit	5 - 20 6 - 1 6 - 2 6 - 3 6 - 4 6 - 5 6 - 6 6 - 7 6 - 8 6 - 10 6 - 11 6 - 12 6 - 13 6 - 14 6 - 15 6 - 16 6 - 17 6 - 18	June 30/98
7 Controls	7 - 1 7 - 2 7 - 3 7 - 4 7 - 5 7 - 6 7 - 7	June 30/98 June 30/98 June 30/98 June 30/98 June 30/98 June 30/98

Chapter	Page	Date
7 Controls	7 - 8 7 - 9 7 - 10 7 - 11 7 - 12 7 - 13 7 - 14 7 - 15 7 - 16 7 - 17 7 - 20 7 - 21 7 - 22 7 - 23 7 - 24 7 - 25 7 - 26 7 - 27 7 - 28 7 - 29 7 - 30	June 30/98
8 Landing gear	8-1 8-2 8-3 8-4 8-5 8-6 8-7 8-6 8-7 8-10 8-11 8-13 8-14 8-15 8-17 8-18 8-19 8-20 8-21 8-22 8-25 8-27 8-28 8-29 8-30	June 30/98



MAINTENANCE MANUAL



INSIDE PLACARDS AND MARKINGS - RIGHT SIDE OF FRONT AND AFT COCKPITS FIG. 3.7-3

1 - front cockpit

II - aft cockpit



MAINTENANCE MANUAL




FIG. 3.7-4 INSIDE PLACARDS AND MARKINGS - FRONT AND AFT INSTRUMENT PANELS

I - front instrument panel

II - aft instrument panel